


**Honeywell**

# Installation Guide



**FocusPRO™ TH6220D**

Programmable Thermostat



69-1785

## Product Application

This thermostat provides electronic control of 24 VAC single-stage and multi-stage heating and cooling systems, or 750 mV heating systems.

### System Types (up to 2 heat/2 cool)

- Gas, oil, or electric heat with air conditioning
- Warm air, hot water, high-efficiency furnaces, heat pumps, steam, gravity
- Heat only — two-wire systems, power to open and close zone valves (Series 20), and normally-open zone valves
- Heat only with fan
- Cool only
- 750 mV heating systems

### Power Options

- Battery power only
- Common wire only
- Common wire with battery backup

### Changeover Options

- Selectable manual or auto-changeover modes

### System Settings

- Heat, Off, Cool, Auto, Em Heat

### Fan Settings

- Auto, On

## Must be installed by a trained, experienced technician

- Read these instructions carefully. Failure to follow these instructions can damage the product or cause a hazardous condition.
- Check the ratings in this booklet to verify that this product is suitable for your application (see page 17).
- Always test for proper operation after installation (see page 13).



#### CAUTION: ELECTRICAL HAZARD

Can cause electrical shock or equipment damage. Disconnect power before beginning installation.



#### MERCURY NOTICE

If this product is replacing a control that contains mercury in a sealed tube, do not place the old control in the trash. Contact your local waste management authority for instructions regarding recycling and proper disposal.

Table of contents

Installation

Pre-installation checklist .....2

Wallplate installation .....3

Wiring.....4

Wiring diagrams .....5

Power options .....10

Thermostat mounting .....10

Appendices

Quick reference to controls.....15

Quick reference to display.....15

Battery replacement.....15

In case of difficulty .....16

Accessories/replacement parts ....17

Specifications .....17

Setup and testing


Installer setup.....11

Installer system test .....13

Explanation of features .....14

Installation tips

Install the thermostat about 5 feet (1.5m) above the floor in an area with good air circulation at average temperature.



- Do not install** in locations where the thermostat can be affected by:
- Drafts or dead spots behind doors and in corners
  - Hot or cold air from ducts
  - Sunlight or radiant heat from appliances
  - Concealed pipes or chimneys
  - Unheated/uncooled areas such as an outside wall behind the thermostat

## Pre-installation checklist

### Package contents

Check to make sure your package includes the following items:



FocusPRO™ TH6220D  
programmable thermostat  
(wallplate attached to back)



Quick  
reference  
card



Operating manual



Wall anchors and  
mounting screws  
(2 each)




AA alkaline  
batteries (2)

### Required tools & supplies


- No. 2 Phillips screwdriver
- Small pocket screwdriver
- Drill
- Drill bit (3/16" for drywall, 7/32" for plaster)
- Hammer
- Pencil
- Electrical tape
- Level (optional)

## Wallplate installation

Insert finger into wire hole and pull to remove wallplate from thermostat.




Insert quick reference card



Remove the wallplate from the thermostat as shown at left, then follow directions below for mounting.

- 1 Insert quick reference card in slot in back of thermostat.
- 2 Pull wires through wire hole.
- 3 Position wallplate on wall, level and mark hole positions with pencil.
- 4 Drill holes at marked positions as shown below, then tap in supplied wall anchors.
- 5 Place wallplate over anchors, insert and tighten mounting screws.


Drill 3/16" holes for drywall.  
Drill 7/32" holes for plaster.



## Wiring



**CAUTION: ELECTRICAL HAZARD.** Can cause electrical shock or equipment damage. Disconnect power before wiring.



### NOTES

#### R & Rc terminals

In single-transformer system, leave metal jumper in place between R & Rc. Remove metal jumper if two-transformer system.

#### C terminal

The C (common wire) terminal is optional when thermostat is powered by batteries.

#### W (O/B) terminal

If thermostat is configured for a heat pump in the Installer Setup, configure changeover valve for cool ("O" factory setting) or heat ("B").

#### L terminal (Output)

Heat pump reset. L terminal powered continuously when thermostat is set to Em Heat. Configure thermostat for 2 heat / 1 cool heat pump in the Installer Setup.

#### Wire specifications

Use 18- to 22-gauge thermostat wire. Shielded cable is not required.

## Wiring

- 1 Loosen screw terminals, insert wires into terminal block, then re-tighten screws.
- 2 Push excess wire back into the wall opening. Keep wires in shaded area as shown at left.
- 3 Plug the wall opening with non-flammable insulation to prevent drafts from affecting thermostat operation.

## Terminal Designations

### Conventional Terminal Letters:

- Y2** 2nd stage compressor contactor
- W2** 2nd stage heat relay
- G** Fan relay
- W** 1st stage heat relay
- C** Common wire from secondary side of cooling system transformer
- Y** 1st stage compressor contactor
- R** Heating power. Connect to secondary side of heating system transformer.
- Rc** Cooling power. Connect to secondary side of cooling system transformer.


### Heat Pump Terminal Letters:

- L** Heat pump reset. L terminal powered continuously when System is set to Em Heat.
- E** Emergency heat relay
- Aux** Auxiliary heat relay
- G** Fan relay
- O/B** Changeover valve for heat pumps
- C** Common wire from secondary side of cooling system transformer.
- Y** Compressor contactor
- R** Heating power. Connect to secondary side of heating system transformer.
- Rc** Cooling power. Connect to secondary side of cooling system transformer.


Wiring diagrams

- 1 Power supply. Provide disconnect means and overload protection as required.
- 2 Factory-installed jumper. Remove for 2-transformer systems only.
- 3 Optional 24VAC common connection.
- 4 In Installer Setup, set system type to **Heat Only**.
- 5 In Installer Setup, set system type to **1Heat/1Cool Heat Pump** & changeover valve to **0** or **B**.
- 6 In Installer Setup, set system type to **2Heat/1Cool Heat Pump**.
- 7 L terminal is powered continuously when thermostat is set to Em Heat.
- 8 Install field jumper between Aux and E if there is no emergency heat relay.
- 9 In Installer Setup, set system type to **2Heat/2Cool conventional**.

Typical 1H/1C system: 1 transformer




Typical 1H/1C system: 2 transformers




Wiring diagrams

- 1 Power supply. Provide disconnect means and overload protection as required.
- 2 Factory-installed jumper. Remove for 2-transformer systems only.
- 3 Optional 24VAC common connection.
- 4 In Installer Setup, set system type to **Heat Only**.
- 5 In Installer Setup, set system type to **1Heat/1Cool Heat Pump** & changeover valve to **0** or **B**.
- 6 In Installer Setup, set system type to **2Heat/1Cool Heat Pump**.
- 7 L terminal is powered continuously when thermostat is set to Em Heat.
- 8 Install field jumper between Aux and E if there is no emergency heat relay.
- 9 In Installer Setup, set system type to **2Heat/2Cool conventional**.

Typical 1H/1C heat pump system



Typical heat-only system







Wiring diagrams

- 1 Power supply. Provide disconnect means and overload protection as required.
- 2 Factory-installed jumper. Remove for 2-transformer systems only.
- 3 Optional 24VAC common connection.
- 4 In Installer Setup, set system type to **Heat Only**.
- 5 In Installer Setup, set system type to **1Heat/1Cool Heat Pump** & changeover valve to **0** or **B**.
- 6 In Installer Setup, set system type to **2Heat/1Cool Heat Pump**.
- 7 L terminal is powered continuously when thermostat is set to Em Heat.
- 8 Install field jumper between Aux and E if there is no emergency heat relay.
- 9 In Installer Setup, set system type to **2Heat/2Cool conventional**.

Typical heat-only system with fan




Heat-only system (Series 20)




Wiring diagrams

- 1 Power supply. Provide disconnect means and overload protection as required.
- 2 Factory-installed jumper. Remove for 2-transformer systems only.
- 3 Optional 24VAC common connection.
- 4 In Installer Setup, set system type to **Heat Only**.
- 5 In Installer Setup, set system type to **1Heat/1Cool Heat Pump** & changeover valve to **0** or **B**.
- 6 In Installer Setup, set system type to **2Heat/1Cool Heat Pump**.
- 7 L terminal is powered continuously when thermostat is set to Em Heat.
- 8 Install field jumper between Aux and E if there is no emergency heat relay.
- 9 In Installer Setup, set system type to **2Heat/2Cool conventional**.

Typical cool-only system




Heat-only system (normally open zone valve)




Wiring diagrams

- 1 Power supply. Provide disconnect means and overload protection as required.
- 2 Factory-installed jumper. Remove for 2-transformer systems only.
- 3 Optional 24VAC common connection.
- 4 In Installer Setup, set system type to **Heat Only**.
- 5 In Installer Setup, set system type to **1Heat/1Cool Heat Pump** & changeover valve to **0** or **B**.
- 6 In Installer Setup, set system type to **2Heat/1Cool Heat Pump**.
- 7 L terminal is powered continuously when thermostat is set to Em Heat.
- 8 Install field jumper between Aux and E if there is no emergency heat relay.
- 9 In Installer Setup, set system type to **2Heat/2Cool conventional**.


Typical 2H/2C system (1 transformer)



Typical 2H/1C heat pump system



## Power options & mounting




### AC Power

The thermostat can be powered by 24 VAC power, or by batteries.

To wire the thermostat for AC power, connect the common side of the cooling transformer to the "C" terminal as shown at left.

**Important:** Remove R/Rc jumper for 2-transformer systems only. (See wiring diagram on page 5.)




Install batteries in back of thermostat (optional if AC powered).

### Battery Power

The thermostat can be powered by batteries alone or, if used with AC power, can provide backup power. During power interruptions the batteries will save time/day settings and power the display.

After installation, batteries can be changed without removing the thermostat from the wall (see page 15).




### To Mount Thermostat

Align the 4 tabs on the wallplate with corresponding slots on the back of the thermostat, then push gently until the thermostat snaps in place.

Installer setup

Follow the procedure below to configure the thermostat to match the installed heating/cooling system, and customize feature operation as desired.



To begin, press and hold the ▲ and FAN buttons until the display changes

Press ▲ or ▼ to change settings  
Press **NEXT** to advance to next function  
Press **DONE** to exit and save settings

Setup Function


Settings & Options

- |   |  |
|---|--|
| <p><b>1 System type</b></p> <p><b>2 Changeover valve</b><br/>(O/B terminal)</p> <p><b>3 Fan control</b><br/>(heating)</p> <p><b>5 Heat cycle rate</b><br/>(CPH: cycles/hour)</p> <p><b>6 Second stage heat cycle rate/<br/>Auxiliary heat</b><br/>(CPH)</p> | <p><b>0 Gas, oil or electric heat with air conditioning</b><br/>1 1 heat/1 cool heat pump<br/>2 Heat only (2-wire systems/power to open &amp; close zone valves/<br/>normally open zone valves)<br/>3 Heat only with fan<br/>4 Cool only<br/>5 2 heat/1 cool heat pump<br/>6 2 heat/2 cool conventional<br/>7 2 heat/1 cool conventional<br/>8 1 heat/2 cool conventional</p> <p><b>0 Changeover valve (O/B terminal energized in cooling)</b><br/>1 Changeover valve (O/B terminal energized in heating)</p> <p><b>0 Gas or oil furnace — equipment controls fan in heating</b><br/>1 Electric furnace — thermostat controls fan in heating</p> <p><b>5 For gas or oil furnaces of less than 90% efficiency</b><br/>1 For steam or gravity systems<br/>3 For hot water systems &amp; furnaces of over 90% efficiency<br/>9 For electric furnaces<br/>[Other cycle rate options: 2, 4, 6, 7, 8, 10, 11 or 12 CPH]</p> <p><b>5 For gas or oil furnaces of less than 90% efficiency</b><br/>1 For steam or gravity systems<br/>3 For hot water systems &amp; furnaces of over 90% efficiency<br/>9 For electric furnaces<br/>[Other cycle rate options: 2, 4, 6, 7, 8, 10, 11 or 12 CPH]</p> |
|---|--|

Continued on next page >

Installer setup

Follow the procedure below to configure the thermostat to match the installed heating/cooling system, and customize feature operation as desired.



To begin, press and hold the ▲ and FAN buttons until the display changes

Press ▲ or ▼ to change settings  
Press **NEXT** to advance to next function  
Press **DONE** to exit and save settings


Setup Function

Settings & Options

8 Emergency heat cycle rate (CPH)	9 For electric emergency heat 1 For steam or gravity systems 3 For hot water systems & furnaces of over 90% efficiency 5 For gas or oil furnaces of less than 90% efficiency [Other cycle rate options: 2, 4, 6, 7, 8, 10, 11 or 12 CPH]
9 Compressor cycle rate (CPH)	3 Recommended for most compressors [Other cycle rate options: 1, 2, 4, 5 or 6 CPH]
10 Second stage compressor cycle rate (CPH)	3 Recommended for most compressors [Other cycle rate options: 1, 2, 4, 5 or 6 CPH]
12 System setting adjustment	0 Manual changeover (Heat/Cool/Off) 1 Auto changeover (Heat/Cool/Auto/Off) **See page 14 2 Auto changeover only (Auto) **See page 14
13 Adaptive Intelligent Recovery™	1 On **See page 14 0 Off
14 Temperature display	0 Fahrenheit 1 Celsius
15 Compressor protection	5 Five-minute compressor off time **See page 14 [Other options: 0, 1, 2, 3 or 4-minute off time]
16 Schedule format	0 5/2 (programmable weekdays and weekends) 1 5/1/1 (weekdays, Saturday & Sunday programmable)
27 Heat temperature range stops	90 Highest heating temperature setting 40-89 Heating temperature range (increments of 1°F, or 0.5°C)
28 Cool temperature range stops	50 Lowest cooling temperature setting 51-99 Cooling temperature range (increments of 1°F, or 0.5°C)

Installer system test

Follow the procedure below to test the heating, cooling and fan.



To begin, press and hold the ▲ and ▼ buttons until the display changes

- Press ▲ to turn on system
- Press ▼ to turn off system
- Press **NEXT** to advance to next test
- Press **DONE** to terminate system test

System Test	System Status
<b>10 Heating system</b>	0 Heat and fan turn off 1 Heat turns on. Fan also turns on immediately if Function 1 is set to "1" or "5," or if Function 3 is set to "1" <b>**See page 11</b> 2 Second stage heat turns on
<b>20 Emergency heating system</b>	0 Heat and fan turn off 1 Heat and fan turn on 2 Second stage heat turns on (Aux)
<b>30 Cooling system</b>	0 Compressor and fan turn off 1 Compressor and fan turn on 2 Second stage compressor turns on
<b>40 Fan system</b>	0 Fan turns off 1 Fan turns on
<b>70 Thermostat information</b> (for reference only)	71 Software revision number (major revisions) 72 Software revision number (minor revisions) 73 Configuration identification code (major) 74 Configuration identification code (minor) 75 Production configuration date code (week) 76 Production configuration date code (year)



**CAUTION: EQUIPMENT DAMAGE HAZARD**  
Compressor protection (minimum off time) is bypassed during testing. To prevent equipment damage, avoid cycling the compressor quickly.

## Auto Changeover (Setup Function 12)

<b>Set</b> Clock/Day/ Schedule	<b>Fan</b> Auto	<b>System</b> Auto
-----------------------------------	--------------------	-----------------------



Auto Changeover is a feature used in climates where both air conditioning and heating are used on the same day. When the system is set to Auto, the thermostat automatically selects heating or cooling depending on the indoor temperature.

Heat and cool settings must be at least 3 degrees apart. The thermostat will automatically adjust settings to maintain this 3-degree separation (called “deadband”).

The 3-degree separation between heating and cooling set temperatures is fixed, and cannot be changed.

## Adaptive Intelligent Recovery™ (Setup Function 13)

Adaptive Intelligent Recovery eliminates guesswork when setting your schedule. It allows the thermostat to “learn” how long your furnace and air conditioner take to reach the temperature you want.

Just set your program schedule to the time you want the house to reach your desired temperature. The thermostat then turns on the heating or cooling at just the right time to reach your scheduled temperature at your scheduled time.

For example: Set the Wake time to 6 am, and the temperature to 70°. The heat will come on before 6 am, so the temperature is 70° by the time you wake at 6.

## Built-in compressor protection (Setup Function 15)

Inside <b>75°</b>	<b>6:30 AM</b>	Cool Setting <b>75°</b>
<b>Set</b> Clock/Day/ Schedule	<b>Fan</b> Auto	<b>System</b> Cool

Cool On

Message flashes until safe restart time has elapsed


This feature helps prevent damage to the compressor in your air conditioning or heat pump system.

Damage can occur if the compressor is restarted too soon after shutdown. This feature forces the compressor to wait for a few minutes before restarting.


During the wait time, the message Cool On or Heat On (heat pumps only) will flash on the display. When the safe wait time has elapsed, the message stops flashing and the compressor turns on.




Quick reference to controls



Quick reference to display screen



Battery replacement



## In case of difficulty

If you have difficulty with your thermostat, please try the suggestions below. Most problems can be corrected quickly and easily.

- |   |  |
|---|--|
| <b>Display is blank</b>   | <ul style="list-style-type: none"><li>• Check circuit breaker and reset if necessary.</li><li>• Make sure power switch at heating &amp; cooling system is on.</li><li>• Make sure furnace door is closed securely.</li><li>• If thermostat is battery powered, make sure fresh AA alkaline batteries are correctly installed (see page 10).</li></ul>  |
| <b>Temperature settings do not change</b>                               | <p>Make sure heating and cooling temperatures are set to acceptable ranges:</p> <ul style="list-style-type: none"><li>• Heat: 40° to 90°F (4.5° to 32°C).</li><li>• Cool: 50° to 99°F (10° to 37°C).</li></ul> <p>Check temperature range stop settings (Function 27 &amp; 28 on page 12).</p>   |
| <b>Heating system does not respond ("Heat On" appears on screen)</b>    | <ul style="list-style-type: none"><li>• Check for 24 Vac at the equipment on the secondary side of the transformer between power and common. If voltage is not present, check the heating equipment to find the cause of the problem.</li><li>• Check for 24 Vac between the heat terminal (W) and the transformer common. If 24 Vac is present, the thermostat is functional. Check the heating equipment to find the cause of the problem.</li><li>• Check for loose or broken wires between the thermostat and the heating equipment.</li></ul> |
| <b>Cooling system does not respond ("Cool On" appears on screen)</b>    | <ul style="list-style-type: none"><li>• Check for 24 Vac at the equipment on the secondary side of the transformer between power and common. If voltage is not present, check the cooling equipment to find the cause of the problem.</li><li>• Check for 24 Vac between the cooling terminal (Y) and the transformer common. If 24 Vac is present, the thermostat is functional. Check the cooling system to find the cause of the problem.</li><li>• Check for loose or broken wires between the thermostat and the cooling equipment.</li></ul> |
| <b>Fan does not turn on in a call for heat</b>                          | <ul style="list-style-type: none"><li>• Check Installer Setup, Function 3 (Fan Control), to make sure the fan control is properly set to match the type of system (see page 11).</li></ul>   |
| <b>Heat pump issues cool air in heat mode, or warm air in cool mode</b> | <ul style="list-style-type: none"><li>• Check Installer Setup, Function 2 (Changeover Valve), to make sure it is properly configured for your system (see page 11).</li></ul>  |
| <b>Heat/cool both on at same time, or heat does not turn off</b>        | <ul style="list-style-type: none"><li>• Check Installer Setup, Function 1 (System Type), to make sure it is set to match the installed heating/cooling equipment (see page 11).</li><li>• Check to make sure heating and cooling wires are not shorted together.</li></ul>   |

In case of difficulty

- Heating equip-  
ment is running  
in cool mode

- Check Installer Setup, Function 1 (System Type), to make sure it is set to match the installed heating/cooling equipment (see page 11).
- Cannot change  
system setting  
to “Heat”

- Check Installer Setup, Function 1 (System Type), to make sure it is set to match the installed heating equipment (see page 11).
  - Change Installer Setup, Function 12 (System Setting) to Manual or Auto Changeover (see page 12).
- Cannot change  
system setting  
to “Cool”

- Check Installer Setup, Function 1 (System Type), to make sure it is set to match the installed cooling equipment (see page 11).
  - Change Installer Setup, Function 12 (System Setting) to Manual or Auto Changeover (see page 12).
- “Heat On” is  
not displayed

- Change the System Setting to Heat, and set the temperature level above the current room temperature.
- “Cool On” is not  
displayed

- Change the System Setting to Cool, and set the temperature level below the current room temperature.
- “Cool On” or  
“Heat On”  
is flashing

- Compressor protection timeout is engaged. Wait 5 minutes for the system to restart safely, without damage to the compressor.

Accessories & replacement parts

Please contact your distributor to order replacement parts.

**Battery holder** .....Part Number 50007072-001

**Cover plate assembly** .....Part Number 50002883-001

(Use to cover marks left by old thermostats.)

Specifications

Temperature Ranges		Electrical Ratings	
• Heat: 40° to 90°F (4.5° to 32°C) • Cool: 50° to 99°F (10° to 37°C)		Terminal	Voltage (50/60Hz)    Running Current
		<b>W (O/B)</b> Heating (Powerpile)	20-30 Vac    0.02-1.0 A 750 mV DC    100 mA DC
<b>Operating Ambient Temperature</b> • 32° to 120°F (0° to 48.9°C)		<b>W2 (Aux)</b> Heating	20-30 Vac    0.02-0.5 A
		<b>Y</b> Cooling	20-30 Vac    0.02-1.0 A
<b>Shipping Temperature</b> • -20° to 120°F (-28.9° to 48.9°C)		<b>Y2</b> Cooling	20-30 Vac    0.02-1.0 A
		<b>G</b> Fan	20-30 Vac    0.02-0.5 A
<b>Operating Relative Humidity</b> • 5% to 90% (non-condensing)		<b>E</b> Emergency heat	20-30 Vac    0.02-1.0 A
		<b>L</b> Heat pump reset	20-30 Vac    0.02-0.5 A
<b>Physical Dimensions</b> • 3-9/16” H x 5-13/16” W x 1-1/2” D • 91 mm H x 147 mm W x 38 mm D			



## Automation and Control Solutions

---

Honeywell International Inc.  
1985 Douglas Drive North  
Golden Valley, MN 55422

Honeywell Limited-Honeywell Limitée  
35 Dynamic Drive  
Scarborough, Ontario M1V 4Z9