



1/2" - 1" SWEAT AND NPT
(SWEAT MODEL PICTURED ABOVE)



1 1/4" - 2" SWEAT
1 1/4" - 3" NPT
(NPT MODEL PICTURED ABOVE)



2 1/2", 3", 4" FLANGED

Circuit Setter® Plus Balance Valves

With NPT, Flanged and Solder Connections

Installation, Operation and Service Instructions

INSTALLER: PLEASE LEAVE THIS MANUAL FOR THE OWNER'S USE.

NOTE: Bell & Gossett does not recommend Circuit Setter Balance Valves to be used for potable water.



SAFETY INSTRUCTION

This safety alert symbol will be used in this manual to draw attention to safety related instructions. When used, the safety alert symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED! FAILURE TO FOLLOW THE INSTRUCTIONS MAY RESULT IN A SAFETY HAZARD.

OPERATIONAL LIMITS

(SOLDER TYPE LIMITS PER ASTM STD. B16.18-1978)

CIRCUIT SETTER STYLE	TYPE OF SOLDER	MAXIMUM LIMITATIONS	
		PRESSURE PSI	TEMPERATURE °F
NPT	—	300	250
SWEAT	95-5 TIN-ANTIMONY	300	200
		250	225
		200	250
2 1/2", 3", 4" FLANGED	—	175	250

DESCRIPTION

Bell & Gossett Circuit Setter Balance Valves are precision engineered valves which function as precise system balancing valves and highly accurate variable orifice flow meters. NPT, Sweat and 2 1/2", 3" and 4" flanged models also function as positive shutoff service valves. Bell & Gossett NPT, Sweat and 2 1/2", 3" and 4" flanged Circuit Setter Balance Valves are equipped with an easy to operate memory stop feature. NPT and Sweat models are also equipped with a drain port feature.



WARNING: Damage to the Circuit Setter or failure of solder sealing joints may occur if these operational limits are exceeded. This can result in water leakage. Failure to follow this instruction can cause serious personal injury and/or property damage.

Bell & Gossett



ITT Industries
Engineered for life

INSTALLATION INSTRUCTIONS

To retain calibrated accuracy, a minimum length of unrestricted straight pipe equivalent to 3-pipe diameters upstream and 1-pipe diameter downstream must be maintained immediately adjacent to Circuit Setter Balance Valves.

Circuit Setter Balance Valves are bi-directional valves and can be installed in most altitudes, however, they should be installed in a position to facilitate the ease of balancing the system.

IMPORTANT: Bell & Gossett Circuit Setter Balance Valves are not recommended for use with meter connections pointing down. Dirt will collect in the connections and foul up the readout valves and readout meters.

NPT and sweat style Circuit Setter Balance Valves are equipped with 1/4" NPT plugged drain port. If the drain port is to be used to drain a riser on the downstream side of a terminal unit, it should be situated on the terminal unit side of the riser when installing the Circuit Setter.

CIRCUIT SETTER BALANCE VALVES WITH SWEAT CONNECTIONS

1. Use a torch with a sharp pointed flame.
2. Clean tube ends and Circuit Setter connections thoroughly.
3. Use 95-5 (Tin-Antimony) solder and a good grade of flux.

CAUTION: Heat associated with the use of silver solder may damage a Circuit Setter voiding the warranty. Do not use silver solder. Failure to follow these instructions could result in property damage and/or moderate personal injury.

CAUTION: Excessive use of solder in a vertical installation may result in damage to the valve seat and ball. Do not use excessive flux. Failure to follow these instructions could result in property damage and/or moderate personal injury.

4. When sweating the joints, first wrap the valve body with a cool wet rag, then direct the flame with care to avoid subjecting the Circuit Setter to excessive heat. Allow the valve body to cool below 200°F before installing the (2) Model RV-125A Readout Valves packaged with the Circuit Setter Balance Valve.

CAUTION: The use of Teflon impregnated pipe compound and Teflon tape on threads provides lubricity. Care should be taken to prevent overtightening of the readout valves which may damage the Circuit Setter.

5. Check soldered connections for leaks. If resoldering is required, remove the readout valves before applying the torch to the connection(s).

CIRCUIT SETTER BALANCE VALVES WITH NPT CONNECTIONS

1. Apply pipe compound conservatively to male connecting fittings only.

CAUTION: The use of Teflon impregnated pipe compound and Teflon tape on threads provides lubricity. Care should be taken to prevent overtightening of the readout valves which may damage the Circuit Setter.

2. Check connections for leaks.

CIRCUIT SETTER BALANCE VALVES WITH 125 PSI ANSI FLANGED CONNECTIONS

Flanged Circuit Setter Balance Valves are not furnished with companion flanges, gaskets, nuts and bolts.

1. When installing Circuit Setter Balance Valves with flanged connections, care should be taken to prevent the gaskets from extending into the inside diameter of the pipe which will cause a blockage that will affect the accuracy of the Circuit Setter.
2. Check connections for leaks.

OPERATION INSTRUCTIONS

HOW TO USE BELL & GOSSETT CIRCUIT SETTER BALANCE VALVES FOR PRE-SET FLOW BALANCING

All Circuit Setter Balance Valves within a common zone, circuit, or system, with a common pump, are brought into balance with each other by establishing a common BALANCE GOVERNING HEAD LOSS as noted.

1. Identify the zone within a given circuit or circuit within a given system with the highest head loss.
2. Establish the value of the head loss in feet of water.
3. Establish the corresponding required GPM.
4. Select the appropriate size Circuit Setter Balance Valve (normally line size) for the required GPM.
5. Using Side #1 of the V91483 Circuit Setter Balance Valve Calculator, set the degree of closure hairline in the red section of the Calculator over the 0° setting for the appropriate size Circuit Setter and read the head loss opposite the required GPM. The setting for this Circuit Setter will remain 0°.
6. Add the head loss in Step "5" to the head loss in Step "2" to establish the Balance Governing Head Loss for the zone or circuit.
7. Subtract the required head loss for each zone circuit from the Balance Governing Head Loss in Step "6" to establish the head loss difference for each zone or circuit which is to be brought into balance with Step "6".

8. The head loss difference in Step "7" and the required GPM in Step "3" are lined up in the white section of Side #1 of the Calculator. The degree of closure for the specific Circuit Setter Balance Valve is shown under the degree of closure hairline in the red section of the Calculator for the appropriate size Circuit Setter.
9. Adjust the Circuit Setter by turning the red knob by hand on sizes $\frac{1}{2}$ " thru 1", or by placing a wrench on the wrench flats provided on sizes $1\frac{1}{4}$ " thru 4" to the set position determined by the preceding procedure.
6. If there are additional branches, repeat the steps in 3, 4 and 5 for each branch.
7. After all branches have been proportionately balanced, measure the full open flows on the Circuit Setters installed on the risers. Calculate the proportional ratio of each riser Circuit Setter and select the one with the lowest proportional ratio. This Circuit Setter is left fully open and the other riser Circuit Setters are adjusted to this same ratio as described in Step "5".
8. Adjust pump flow so that circuits are receiving their design flow. This can be accomplished by adjusting a Circuit Setter Balance Valve installed on the pump discharge or by changing the pump impeller size.



WARNING: It is possible, depending on the age or condition of the stem seal, for some liquid to escape during Circuit Setter adjustment. Do not have eyes or face on a level with the sides of the Circuit Setter. Failure to follow this warning could result in serious personal injury.

NOTES:

1. Head losses in Steps "6" and "2" are a fixed head requirement the zone, circuit, or system pump, as required, must overcome.
2. Refer to the G95872 prewired tag packaged with the Circuit Setter Balance Valve and fill in the appropriate information. Attach the tag to the Circuit Setter for future reference.

HOW TO USE BELL & GOSSETT CIRCUIT SETTERS TO PROPORTIONAL BALANCE A SYSTEM

1. Open fully all Circuit Setters on a single pump system.
2. If more than one branch circuit is used, start the balance procedure by reading all of the flows to the units in a branch. Each unit (coil) should have its own Circuit Setter for flow balancing. Using Bell & Gossett RP-250B readout probes, sequentially attach a Bell & Gossett differential pressure readout kit to the readout valves on each Circuit Setter Balance Valve.



WARNING: Hot water leakage can occur from readout valves during probe insertion and during hookup of readout kit. Follow the instruction manuals supplied with readout probes and readout kits for safe use. Failure to follow these instructions could result in serious personal injury or death and property damage.

3. Using side 2 of the Bell & Gossett Circuit Setter Balance Valve Calculator, with the top hairline set on zero for the size Circuit Setter being read, read the flow corresponding to the pressure drop read with the readout kit.
4. Calculate the ratio of the actual flow to the design flow for each unit in the branch. This is the proportional flow rate. (Actual flow divide by design flow.)
5. Select the Circuit Setter with the lowest proportional flow rate. This Circuit Setter is left in the full open position. Every other Circuit Setter in the branch is then reset to the same proportional flow rate.

IMPORTANT: If a high degree of throttling of flow at pump discharge is required, Bell & Gossett recommends that the pump impeller be sized to produce design flow. This will reduce electrical energy consumption.

HOW TO USE BELL & GOSSETT CIRCUIT SETTER BALANCE VALVES AS FLOW METERS

1. Energize the zone, circuit and/or system pump(s) as applicable.
2. Using Bell & Gossett Model RP-250B Readout Probes, sequentially attach a Bell & Gossett differential pressure readout kit to the readout valves on each Circuit Setter Balance Valve.
3. Read the differential pressure across the orifice of the Circuit Setter Balance Valve.



WARNING: Hot water leakage can occur from readout valves during probe insertion and during hookup of readout kit. Follow the instruction manuals supplied with readout probes and readout kits for safe use. Failure to follow these instructions could result in serious personal injury or death and property damage.

4. Using Side #2 of the Circuit Setter Balance Valve Calculator, set the hairline over the degree of closure as indicated by the part of the red plastic knob or indicator plate parallel to the degree of closure noted on the calibration plate, and read actual GPM flowing through the Circuit Setter opposite the gauge reading head loss noted in the white section of Side #2.

NOTE:

If the system contains a liquid with a specific gravity and/or viscosity higher or lower than that of water, apply the appropriate correction factor noted in these instructions to obtain the actual GPM for the system liquid.

HOW TO USE BELL & GOSSETT CIRCUIT SETTER BALANCE VALVES AS AN ISOLATION VALVE

1. Move the adjustment knob or stem until the position indicator aligns with the closed position on the calibration plate.
2. Close the isolation valve on the other side of the equipment to be serviced.
3. Open the drain valve to drain the system between the Circuit Setter and second isolation valve.



WARNING: Check for proper sealing when using as an isolation valve. If the seat is not sealing properly liquid will continue to flow from the drain valves. In this case the Circuit Setter must be isolated from the system and replaced. Failure to follow these instructions could result in serious personal injury or death and property damage.

HOW TO USE THE MEMORY STOP FEATURE

For sizes 1/2" thru 4":

1. Make the final degree of closure setting.
2. Loosen the memory stop locking screw in the slot on the top of the red knob.
3. Slide the memory stop screw in the slot (counter-clockwise for 1/2" thru 1" sizes and clockwise for 1 1/4" thru 4" sizes) until the screw stops.
4. Tighten the memory stop screw.

SERVICE INSTRUCTIONS

Periodically inspect the Circuit Setter for signs of leakage or corrosion.



WARNING: Corrosion or leakage are indications that the Circuit Setter must be replaced. Failure to follow these instructions could result in serious personal injury or death and property damage.

INSULATION

Bell & Gossett recommends that insulation be attached to the Circuit Setter after the system has been balanced and the completed G95872 tag has been wired to the Circuit Setter.

NOTE:

Tape or other acceptable means should be used to secure the insulation to the Circuit Setter Balance Valve.

B&G CIRCUIT SETTER CORRECTION FACTORS FOR VISCOSITY AND SPECIFIC GRAVITY

$$GPM_f = \frac{\emptyset}{\sqrt{S.G.}} GPM_s$$

$$f = \frac{\emptyset}{\sqrt{S.G.}}$$

$$GPM_f = f GPM_s$$

GPM_f – FLUID FLOW

GPM_s – FLOW THRU SETTER
(a MEASURED CONDITIONS)

\emptyset – VISCOSITY CORRECTION

S.G. – SPECIFIC GRAVITY (TO WATER)

VISCOSITY CENTIPOISE		1	10	15	25	35	60	100	200	500
\emptyset		1	.95	.90	.85	.80	.75	.70	.65	.60
S.G.	$\sqrt{S.G.}$	f								
.60	.775	1.29	.123	1.16	1.10	1.03	.97	.90	.84	.78
.65	.806	1.24	1.18	1.12	1.05	.99	.93	.87	.81	.75
.70	.837	1.20	1.14	1.08	1.02	.96	.90	.84	.78	.72
.75	.866	1.16	1.10	1.04	.98	.92	.87	.81	.75	.69
.80	.894	1.12	1.06	1.01	.95	.89	.84	.78	.73	.67
.85	.922	1.08	1.03	.98	.92	.87	.81	.76	.71	.65
.90	.949	1.05	1.00	.95	.90	.84	.79	.74	.69	.63
.95	.975	1.03	.97	.92	.87	.82	.77	.72	.67	.62
1.00	1.00	1.00	.95	.90	.85	.80	.75	.70	.65	.60
1.05	1.025	.98	.93	.88	.83	.78	.73	.68	.63	.59
1.10	1.049	.95	.91	.86	.81	.76	.72	.67	.62	.57
1.15	1.072	.93	.89	.84	.79	.75	.70	.65	.61	.56
1.20	1.096	.91	.87	.82	.78	.73	.68	.64	.59	.54
1.25	1.118	.89	.85	.81	.76	.72	.67	.63	.58	.54
1.30	1.140	.88	.84	.79	.75	.70	.66	.62	.57	.53
1.35	1.162	.86	.82	.78	.73	.69	.65	.60	.56	.52
1.40	1.183	.85	.80	.76	.72	.68	.63	.59	.55	.51



ITT Industries

Bell & Gossett

USA
Bell & Gossett
8200 N. Austin Avenue
Morton Grove, IL 60053
Phone: (847) 966-3700
Facsimile: (847) 966-9052
www.bellgossett.com



ISO 9001
Certified

INTL.
Bell & Gossett / Export Dept.
8200 N. Austin Avenue
Morton Grove, IL 60053
Phone: (847) 966-3700
Facsimile: (847) 966-8366
www.bellgossett.com

CANADA
Fluid Products Canada
55 Royal Road
Guelph, Ontario,
N1H 1T1, Canada
Phone: (519) 821-1900
www.itfpc.ca