


A. HVAC CONTRACTOR SHALL PROVIDE SUPPLEMENTAL STEEL SUPPORTS AS REQUIRED FOR PIPE RISERS IN SHAFTS.

KEYED NOTES

1. CONDENSER WATER TOWER BYPASS ASSEMBLY (SEPARATE CONTROL VALVES WITH ELECTRIC VALVE ACTUATORS AND PILOT POSITION'S).
2. CHILLED WATER DIFFERENTIAL PRESSURE BYPASS ASSEMBLY.
3. CONNECTION TO REDUCED PRESSURE BACKFLOW PREVENTER (RPBP) BY HVAC. RPBP BY PLUMBING. REFER TO MICROFAB DRAWING QP2.2.
4. CENTRAL BRANCH STRAINER ASSEMBLY PER DETAIL 1 ON DRAWING M5.3.
5. CONNECT 10" CWR TO INTEGRAL CWR PIPING INSIDE CT-1; CT-2.
6. VENT PIPE ROUTED THROUGH MICROFAB AREA.
7. POINT OF DISCHARGE SHALL BE 20'-0" (MINIMUM) AWAY FROM OPENINGS INTO THE BUILDING.
8. CONNECTION TO REDUCED PRESSURE BACKFLOW PREVENTER (RPBP) BY HVAC. RPBP BY PLUMBING. REFER TO DRAWING P2.1.



Jan 04, 2006 - 1:23pm  
Proc User: